

Crestron **TSW-550/750/1050**

5"/7"/10.1" Touch Screens

Configuration Guide



The specific patents that cover Crestron products are listed at patents.crestron.com.

Crestron, the Crestron logo, and Rava are either trademarks or registered trademarks of Crestron Electronics, Inc. in the United States and/or other countries. Other trademarks, registered trademarks, and trade names may be used in this document to refer to either the entities claiming the marks and names or their products. Crestron disclaims any proprietary interest in the marks and names of others. *Crestron is not responsible for errors in typography or photography.*

This document was written by the Technical Publications department at Crestron.
©2013 Crestron Electronics, Inc.

Contents

5"/7"/10.1" Touch Screens: TSW-550/750/1050	1
Access the Setup Screens.....	1
Configure the Touch Screen	3
Ethernet Setup	3
IP Table Setup	4
Audio Setup.....	6
Display Setup	7
Standby Timeout	7
Diagnostics	8
About.....	11
Save & Exit	11

5"/7"/10.1" Touch Screens: TSW-550/750/1050

Access the Setup Screens

The "Setup" menu is the starting point for configuring the TSW-550, TSW-750 and TSW-1050 touch screens from Crestron®.


NOTE: If no project has been loaded or if an invalid project has been loaded, the touch screen defaults to the "Setup" menu.

The setup screens enable basic configuration procedures prior to regular operation of the touch screen.


During regular operation of the touch screen, there are two ways to activate the setup functions:

1. Place a button on the project main page and assign the reserved join number (17242) that activates setup.
2. Press hard keys 1, 2, 3 and 4, to the right of the touch screen display, in sequence twice (i.e., press 1, 2, 3, 4, 1, 2, 3, 4) within a five second period.

Button Numbering



The "Setup" menu is displayed.

"Setup" Menu


The "Setup" menu is comprised of buttons for **Ethernet Setup**, **IP Table Setup**, **Audio Setup**, **Display Setup**, **Standby Timeout** and **Diagnostics**. In addition, there is an **About** button that provides information about the touch screen and a **Save & Exit** button. The functions of each are detailed in the next section of this guide.

Configure the Touch Screen

Ethernet Setup

On the “Setup” menu, touch **Ethernet Setup** to display the “Ethernet Setup” menu.


“Ethernet Setup” Menu



The “Ethernet Setup” menu displays the touch screen’s *Mac* and *IP Address*, *Subnet Mask*, *Def Router*, *Primary DNS*, *Secondary DNS*, *Hostname* and *Domain*. There are controls for turning *DHCP On* or *Off* as well as a **Static IP Settings** button, which provides access to controls which allow editing of these settings. This screen also contains a *Link* indicator to show the status of the Ethernet connection.



Touch **Static IP Settings** to display the “Ethernet Setup – Static IPs” screen.

“Ethernet Setup – Static IPs” Screen




To edit the *Static IP Address*, *Static Subnet Mask*, *Static Default Router*, *Preferred DNS* or *Alternate Preferred DNS*, touch the button directly under the label for the entry to edit. The on-screen numeric keypad opens.

On-Screen Numeric Keypad

Use the keypad to make the new entry. Touch the “x” in the text field to clear any previous entry. Touch  to delete the last digit. Touch **Save** to save a new entry or  to return to the “Ethernet Setup – Static IPs” screen.

After new settings have been saved, touch **Reboot to Apply Changes** on the “Ethernet Setup – Static IPs” screen to reboot the touch screen, so the new settings can take effect.

If not making any changes, touch  to return to the “Ethernet Setup” menu.

Touch  again to return to the “Setup” menu.


IP Table Setup

On the “Setup” menu, touch **IP Table Setup** to display the “Ethernet Setup – IP Table” menu.

“Ethernet Setup –IP Table” Menu

The “Ethernet Setup – IP Table” menu displays up to four IP table settings, each of which has an *Online* indicator. To add or edit an entry, touch the **Add/Edit** button to its left. The “Ethernet Setup – Edit IP Table Entry” screen is displayed.



“Ethernet Setup –Edit IP Table Entry” Screen



Touch the field below *CIP ID* to display the on-screen hex keypad.

On-Screen Hex Keypad




Use the keypad to make the new entry. Touch the “x” in the text field to clear any previous entry. Touch  to delete the last digit. Touch **Save** to save a new entry or  to return to the “Ethernet Setup – Edit IP Table Entry” screen.

Touch the field below *IP Address/Hostname* to display the on-screen keyboard.


On-Screen Keyboard

Use the keyboard to make the new entry. Touch **Cancel** to return to the “Ethernet Setup – Edit IP Table Entry” screen. Touch the “x” in the text field to clear any

previous entry. Touch  to delete the last digit. Touch **Save** to save a new entry and return to the “Ethernet Setup – Edit IP Table Entry” screen.

On the “Ethernet Setup – Edit IP Table Entry” screen, touch **Save Entry** to save the current entry or **Delete Entry** to clear it.

If not making any changes, touch  to return to the “Ethernet Setup – IP Table” menu.

Touch  again to return to the “Setup” menu.


Audio Setup

On the “Setup” menu, touch **Audio Setup** to display the “Audio Setup” screen.

“Audio Setup” Screen

The “Audio Setup” screen provides controls for muting (or unmuting) the audio, adjusting level for both *Master Volume* and *Media Volume*, as well as a control for

playing a test .wav file. The *Media Volume* controls adjust H.264 streaming media level in relation to the *Master Volume* controls.

Touch  to return to the “Setup” menu.


Display Setup

On the “Setup” menu, touch **Display Setup** to enter the “Display Setup” screen.

“Display Setup” Screen




The “Display Setup” screen provides controls for *LCD (Screen) Brightness* and **On** and **Off** controls for *Hard Key Wakes LCD*.

Touch  to return to the “Setup” menu.


Standby Timeout

On the “Setup” menu, touch **Standby Timeout** to display the “Standby Timeout” screen.

“Standby Timeout” Screen



The “Standby Timeout” screen provides controls to adjust standby timeout from 0 to 120 minutes.

Touch  to return to the “Setup” menu.

Diagnostics

On the “Setup” menu, touch **Diagnostics** to display the “Diagnostics” menu.

“Diagnostics” Menu




The “Diagnostics” menu displays the CPU temperature, *Available Memory* and contains controls to run a **Keypad Test**, **Touch Test**, **Rava Test** and **Mic Test**. In addition there are controls to initiate touch screen calibration and to open various test screens. These are explained in the paragraphs that follow.


Keypad Test

On the “Diagnostics” menu, touch **Keypad Test** to display the “Diagnostics – Keypad Test” screen.

“Diagnostics – Keypad Test” Screen




The “Diagnostics - Keypad” screen can be used to test the function of the hard key push buttons on the right side of the screen. When a button is pressed, its corresponding indication on the screen lights.

Touch  to return to the “Diagnostics” menu.

Touch Test

On the “Diagnostics” menu, touch **Touch Test** to display the touch test screen.


Touch Test Screen



The touch test screen can be used to test the function of the screen. When a location button (the “x” buttons or the “o” button) is touched, its indication on the screen lights. This screen also contains a **Calibrate** button to initiate touch screen calibration.

During touch screen calibration, a crosshair appears at the center of the screen. Touch the center of the crosshair, which then moves to the upper left part of the screen. Touch the center of the crosshair and it moves to another part of the screen. Continue touching the center of the crosshair until calibration is complete.

NOTE: When touching the screen during calibration, be as accurate as possible.

Touch  to return to the “Diagnostics” menu.


Calibrate

On the “Diagnostics” menu, touch **Calibrate** to initiate the screen calibration procedure. Refer to “Touch Test” above for details.


Test Patterns

On the “Diagnostics” menu, touch **Test Patterns** to display the “Diagnostics - Test Patterns” screen.

“Diagnostics - Test Patterns” Screen




The “Diagnostics - Test Patterns” screen contains buttons for selecting the different available test patterns: **Display Color Bars**, **Display Vertical Lines**, **Display Gray Scale**, **Display Grid Pattern** and **Display Test Pattern**.

Touch  to return to the “Diagnostics” menu.


Rava Test

On the “Diagnostics” menu, touch **Rava Test** to display the “Diagnostics – Rava” screen.

“Diagnostics - Rava” Screen




The “Diagnostics - Rava” screen provides controls for testing the use of Crestron’s Rava™ SIP Intercom with the TSW-550/750/1050. They can be used to test projects and settings. If the intercom works but the project does not, there is an issue with the project; if the intercom does not work, there is an issue with the settings.

Touch  to return to the “Diagnostics” menu.

Mic Test

On the “Diagnostics” menu, touch **Mic Test** to begin a microphone test. The touch screen records audio for five seconds and then plays back the recorded sound.


The built-in microphone (located in the lower right corner of the touch screen) will be used to record your voice and play it back to confirm the microphone is functioning. When playback is finished, the display returns to the “Diagnostics” menu.

Touch  to return to the “Setup” menu.


About

On the “Setup” menu, touch **About** to display the “About” screen.

“About” Screen



The “About” screen displays information about the touch screen, including the currently loaded firmware and operating system versions.

Touch  to return to the “Setup” menu.

Save & Exit

On the “Setup” menu, touch **Save & Exit** to save all settings, exit the setup screens and return to the main project.



Crestron Electronics, Inc.
15 Volvo Drive Rockleigh, NJ 07647
Tel: 888.CRESTRON
Fax: 201.767.7576
www.crestron.com



**Configuration Guide – DOC. 7366C
(2033269)**

06.13

Specifications subject to
change without notice.