Kramer Electronics, Ltd.



USER MANUAL

Model:

VP-8

1:8 VGA/UXGA Distributor

Contents

Contents

1	Introduction	1			
2	Getting Started	1			
3	Overview	1			
4	Your VP-8 1:8 VGA/UXGA Distributor	3			
4.1	Your VP-8 1:8 VGA/UXGA Distributor	3			
4.2	Your VP-8 1:8 VGA/UXGA Distributor Underside	4			
5	Using Your VP-8 1:8 VGA/UXGA Distributor	5			
6	Technical Specifications	6			
Figure Figure	ares e 1: VP-8 1:8 VGA/UXGA Distributor	3			
_		3 4			
Figure 2: VP-8 1:8 VGA/UXGA Distributor Underside Figure 3: Connecting the VP-8 1:8 VGA/UXGA Distributor					
Tab	les				
Table	1: Front Panel VP-8 1:8 VGA/UXGA Distributor Features	3			
Table 2: Rear Panel VP-8 1:8 VGA/UXGA Distributor Features					
Table	Table 3: VP-8 1:8 VGA/UXGA Distributor Features				
Table	Γable 4: Technical Specifications of the VP-8 1:8 VGA/UXGA Distributor				



This addendum adds the following information to the user manual:



Caution – No operator-serviceable parts inside unit.

Warning – Use only the Kramer Electronics input power wall adapter that is provided with this unit¹.

Warning – Disconnect power and unplug unit from wall before installing or removing device or servicing unit.

¹ For example: model number AD2512C, part number 2535-000251



1 Introduction

Welcome to Kramer Electronics (since 1981): a world of unique, creative and affordable solutions to the infinite range of problems that confront the video, audio and presentation professional on a daily basis. In recent years, we have redesigned and upgraded most of our line, making the best even better! Our 350-plus different models now appear in 8 Groups¹, which are clearly defined by function.

Congratulations on purchasing your Kramer VP-8 which is ideal for:

- Any professional system requiring high quality VGA/UXGA distribution to multiple monitors and/or projectors
- Larger distribution systems, made by easily cascading several machines

The package includes the following items:

- VP-8 1:8 VGA/UXGA Distributor
- Power adapter (12V DC Input)
- This user manual²

2 Getting Started

We recommend that you:

- Unpack the equipment carefully and save the original box and packaging materials for possible future shipment
 - Review the contents of this user manual
 - Use Kramer high performance high resolution cables³

3 Overview

The high performance **VP-8** is a 1:8 distribution amplifier for VGA/UXGA signals. The **VP-8** 1:8 VGA/UXGA Distributor:

 Lets you select analog or digital sync inputs via a pair of underside switches⁴

⁴ Note that both the Hs (horizontal sync) switch and the Vs (vertical sync) switch MUST be set identically



1

¹ GROUP 1: Distribution Amplifiers; GROUP 2: Video and Audio Switchers, Matrix Switchers and Controllers; GROUP 3: Video, Audio, VGA/XGA Processors; GROUP 4: Interfaces and Sync Processors; GROUP 5: Twisted Pair Interfaces;

GROUP 6: Accessories and Rack Adapters; GROUP 7: Scan Converters and Scalers; and GROUP 8: Cables and Connectors

² Download up-to-date Kramer user manuals from the Internet at this URL: http://www.kramerelectronics.com

³ The complete list of Kramer cables is on our Web site at http://www.kramerelectronics.com

- Features an underside switch for ID Bit control¹
- Has video bandwidth that exceeds 400MHz, making it suitable for the highest resolution graphics signal distribution as well as for HDTV signal distribution
- Accepts one input, provides necessary buffering and isolation, and distributes the signal to 8 identical outputs
 - Is 12VDC fed and is housed in a half 19" enclosure

To achieve the best performance:

- Connect only good quality connection cables, thus avoiding interference, deterioration in signal quality due to poor matching, and elevated noise levels (often associated with low quality cables)
- Avoid interference from neighboring electrical appliances that may adversely influence signal quality and position your Kramer **VP-8** away from moisture, excessive sunlight and dust

KRAMER: SIMPLE CREATIVE TECHNOLOGY

¹ Sometimes notebook computers refuse to output a VGA signal to an external VGA monitor. By setting the ID BIT to ON, the notebook will output to an external VGA monitor


4 Your VP-8 1:8 VGA/UXGA Distributor

This section describes the **VP-8**:

- Front and rear panels, see section 4.1
- Underside, see section 4.2

4.1 Your VP-8 1:8 VGA/UXGA Distributor

Figure 1, Table 1, and Table 2 define the **VP-8** 1:8 VGA/UXGA Distributor:






Figure 1: VP-8 1:8 VGA/UXGA Distributor

Table 1: Front Panel VP-8 1:8 VGA/UXGA Distributor Features

#	Feature	Function
1	POWER Switch	Illuminated switch for turning the unit ON or OFF

Table 2: Rear Panel VP-8 1:8 VGA/UXGA Distributor Features

#	Feature	Function
2	INPUT HD15F Connector	Connect to the VGA/UXGA source
3	OUTPUT HD15F Connector	Connect to the VGA/UXGA acceptor (from 1 to 8)
4	12V DC	+12V DC connector for powering the unit



4.2 Your VP-8 1:8 VGA/UXGA Distributor Underside

Figure 2 and Table 3 define the underside of the 1:8 VGA/UXGA Distributor:




Figure 2: VP-8 1:8 VGA/UXGA Distributor Underside

Table 3: VP-8 1:8 VGA/UXGA Distributor Features

#	Feature	Function
1	ID BIT CONTROL Switch	Slide to the left to set to ON ¹ ; to the right to set to OFF
2	H sync (Horizontal Sync) Switch	Set both switches ² to Hi-Z (TTL ³) if the source is, for
3	V sync (Vertical Sync) Switch	example, a digital graphics card. Set both switches to 75Ω (ANALOG) if the source is analog based, for example, an RGBHV source with coaxial cable for sync

¹ The default. Enabling the notebook or laptop to output a VGA signal to an external VGA monitor

_

² Both the H sync switch and the V sync switch MUST be set identically (no harm will occur to the graphics source if the switches are set to the wrong direction)

^{3 &}quot;Transistor-Transistor Logic" is a term used in digital electronics describing the ability of a device or circuit to be connected directly to the input or output of digital equipment. Such compatibility eliminates the need for interfacing circuitry

5 Using Your VP-8 1:8 VGA/UXGA Distributor

You can use the **VP-8** to output the *VGA/UXGA* signal from a laptop or a PC. To output the XGA signal from a laptop's graphics card to up to 7 monitors and a projector, using a **VP-8** (as the example in Figure 3 illustrates), do the following:

- Connect an XGA source (for example, a laptop's graphics card) to the INPUT HD15F connector.
- 2. Connect the OUTPUT HD15F connectors to up to 8 acceptors. For example, connect the OUTPUT connectors 1 to 7 to Monitors 1 to 7, and connect the OUTPUT 8 connector to a Projector.
- 3. On the underside of the **VP-8**:
 - Set both the H sync switch and the V sync switch to Hi-Z (TTL)
 - Slide the ID Bit switch to the left to set to ON
- 4. Connect the 12V DC power adapter to the power socket and connect the adapter to the mains electricity (not illustrated in Figure 3).




Figure 3: Connecting the VP-8 1:8 VGA/UXGA Distributor

¹ Not all the outputs have to be connected, connect only those that are required and leave the other outputs unconnected



_

6 Technical Specifications

Table 4 includes the technical specifications:

Table 4: Technical Specifications of the VP-8 1:8 VGA/UXGA Distributor

INPUTS:	1 VGA/UXGA on an HD15F connector
OUTPUTS:	8 VGA/UXGA on HD15F connectors
MAX. OUTPUT LEVEL:	1.9Vpp
BANDWIDTH (-3dB):	400MHz, Fully Loaded
DIFF. GAIN:	0.04%
DIFF. PHASE:	0.03 Deg
K-FACTOR:	< 0.1%
S/N RATIO:	78dB
CONTROLS:	On the underside: pair of ANALOG/TTL switches for H sync (Horizontal Sync) and V sync (Vertical Sync); ID Bit switch (PIN 4)
COUPLING:	DC
POWER SOURCE:	12VDC 180mA
DIMENSIONS:	22cm x 18cm x 4.5cm (8.7" x 7" x 1.7"), W, D, H, (half 19", 1U)
WEIGHT:	1.2kg (2.64lbs)
ACCESSORIES:	Power adapter
OPTIONS:	19" rack adapter RK-80 (holds 2 units)

¹ Specifications are subject to change without notice

LIMITED WARRANTY

Kramer Electronics (hereafter Kramer) warrants this product free from defects in material and workmanship under the following terms.

HOW LONG IS THE WARRANTY

Labor and parts are warranted for three years from the date of the first customer purchase.

WHO IS PROTECTED?

Only the first purchase customer may enforce this warranty.

WHAT IS COVERED AND WHAT IS NOT COVERED

Except as below, this warranty covers all defects in material or workmanship in this product. The following are not covered by the warranty:

- Any product which is not distributed by Kramer, or which is not purchased from an authorized Kramer dealer. If you are
 uncertain as to whether a dealer is authorized, please contact Kramer at one of the agents listed in the web site
 www.kramerelectronics.com.
- 2. Any product, on which the serial number has been defaced, modified or removed.
- 3. Damage, deterioration or malfunction resulting from:
 - i) Accident, misuse, abuse, neglect, fire, water, lightning or other acts of nature
 - ii) Product modification, or failure to follow instructions supplied with the product
 - iii) Repair or attempted repair by anyone not authorized by Kramer
 - iv) Any shipment of the product (claims must be presented to the carrier)
 - v) Removal or installation of the product
 - vi) Any other cause, which does not relate to a product defect
 - vii) Cartons, equipment enclosures, cables or accessories used in conjunction with the product

WHAT WE WILL PAY FOR AND WHAT WE WILL NOT PAY FOR

We will pay labor and material expenses for covered items. We will not pay for the following:

- Removal or installations charges.
- Costs of initial technical adjustments (set-up), including adjustment of user controls or programming. These costs are the responsibility of the Kramer dealer from whom the product was purchased.
- Shipping charges.

HOW YOU CAN GET WARRANTY SERVICE

- 1. To obtain service on you product, you must take or ship it prepaid to any authorized Kramer service center.
- Whenever warranty service is required, the original dated invoice (or a copy) must be presented as proof of warranty coverage, and should be included in any shipment of the product. Please also include in any mailing a contact name, company, address, and a description of the problem(s).
- . For the name of the nearest Kramer authorized service center, consult your authorized dealer.

LIMITATION OF IMPLIED WARRANTIES

All implied warranties, including warranties of merchantability and fitness for a particular purpose, are limited in duration to the length of this warranty.

EXCLUSION OF DAMAGES

The liability of Kramer for any effective products is limited to the repair or replacement of the product at our option. Kramer shall not be liable for:

- Damage to other property caused by defects in this product, damages based upon inconvenience, loss of use of the product, loss
 of time, commercial loss; or:
- Any other damages, whether incidental, consequential or otherwise. Some countries may not allow limitations on how long an implied warranty lasts and/or do not allow the exclusion or limitation of incidental or consequential damages, so the above limitations and exclusions may not apply to you.

This warranty gives you specific legal rights, and you may also have other rights, which vary from place to place.

NOTE: All products returned to Kramer for service must have prior approval. This may be obtained from your dealer.

This equipment has been tested to determine compliance with the requirements of: EN-50081: "Electromagnetic compatibility (EMC);

"Electromagnetic compatibility (EMC); generic emission standard.

Part 1: Residential, commercial and light industry"

EN-50082: "Electromagnetic compatibility (EMC) generic immunity standard.

Part 1: Residential, commercial and light industry environment".

CFR-47: FCC Rules and Regulations:

Part 15: "Radio frequency devices

Subpart B – Unintentional radiators"

CAUTION!

- Servicing the machines can only be done by an authorized Kramer technician. Any user who makes changes or modifications to the unit without the expressed approval of the manufacturer will void user authority to operate the equipment.
- Please use recommended interconnection cables to connect the machine to other components.





For the latest information on our products and a list of Kramer distributors, visit our Web site: www.kramerelectronics.com, where updates to this user manual may be found.

We welcome your questions, comments and feedback.





Kramer Electronics, Ltd.

Web site: www.kramerelectronics.com E-mail: info@kramerel.com P/N: 2900-000035 REV 1